

Report for:

Mr. Brian Poplarchick
LaBella Associates, D.P.C
1000 Dunham Drive, Suite B
Dunmore, PA 18512

Regarding: Project: ESASD 2200223; ESASD Smithfield Elementary
EML ID: 2339968

Approved by:

Dates of Analysis:
Spore trap analysis: 01-27-2020



Technical Manager
Ariunaa Jalsrai

Service SOPs: Spore trap analysis (EM-MY-S-1038)
AIHA-LAP, LLC accredited service, Lab ID #103005

All samples were received in acceptable condition unless noted in the Report Comments portion in the body of the report. Due to the nature of the analyses performed, field blank correction of results is not applied. The results relate only to the samples as received. Sample air volume is supplied by the client.

Eurofins EMLab P&K ("the Company") shall have no liability to the client or the client's customer with respect to decisions or recommendations made, actions taken or courses of conduct implemented by either the client or the client's customer as a result of or based upon the Test Results. In no event shall the Company be liable to the client with respect to the Test Results except for the Company's own willful misconduct or gross negligence nor shall the Company be liable for incidental or consequential damages or lost profits or revenues to the fullest extent such liability may be disclaimed by law, even if the Company has been advised of the possibility of such damages, lost profits or lost revenues. In no event shall the Company's liability with respect to the Test Results exceed the amount paid to the Company by the client therefor.

Eurofins EMLab P&K's LabServe® reporting system includes automated fail-safes to ensure that all AIHA-LAP, LLC quality requirements are met and notifications are added to reports when any quality steps remain pending.

Client: LaBella Associates, D.P.C
C/O: Mr. Brian Poplarchick
Re: ESASD 2200223; ESASD Smithfield ElementaryDate of Sampling: 01-22-2020
Date of Receipt: 01-23-2020
Date of Report: 01-27-2020**SPORE TRAP REPORT: NON-VIABLE METHODOLOGY**

Location:	001: Smithfield Elementary Main Office			002: Smithfield Elementary Rm. 3 Guidance		
Comments (see below)	None			None		
Lab ID-Version‡:	11141356-1			11141357-1		
Analysis Date:	01/27/2020			01/27/2020		
	raw ct.	% read	spores/m3	raw ct.	% read	spores/m3
Ascospores						
Basidiospores	1	25	53			
Chaetomium						
Cladosporium						
Curvularia						
Epicoccum						
Fusarium						
Myrothecium						
Nigrospora						
Other brown	1	100	13	1	100	13
Other colorless						
Penicillium/Aspergillus types†	3	25	160	5	25	270
Pithomyces						
Rusts						
Smuts, Periconia, Myxomycetes				1	100	13
Stachybotrys						
Stemphylium						
Torula						
Ulocladium						
Zygomycetes						
Background debris (1-4+)††	2+			2+		
Hyphal fragments/m3	13			13		
Pollen/m3	< 13			< 13		
Skin cells (1-4+)	2+			2+		
Sample volume (liters)	75			75		
§ TOTAL SPORES/m3			230			290

Comments:

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

† The spores of *Aspergillus* and *Penicillium* (and others such as *Acremonium*, *Paecilomyces*) are small and round with very few distinguishing characteristics. They cannot be differentiated by non-viable sampling methods. Also, some species with very small spores are easily missed, and may be undercounted.

†† Background debris indicates the amount of non-biological particulate matter present on the trace (dust in the air) and the resulting visibility for the analyst. It is rated from 1+ (low) to 4+ (high). Counts from areas with 4+ background debris should be regarded as minimal counts and may be higher than reported. It is important to account for samples volumes when evaluating dust levels.

The analytical sensitivity is the spores/m³ divided by the raw count, expressed in spores/m³. The limit of detection is the analytical sensitivity (in spores/m³) multiplied by the sample volume (in liters) divided by 1000 liters.

For more information regarding analytical sensitivity, please contact QA by calling the laboratory.

‡ A "Version" indicated by -"x" after the Lab ID# with a value greater than 1 indicates a sample with amended data. The revision number is reflected by the value of "x".

§ Total Spores/m³ has been rounded to two significant figures to reflect analytical precision.

Client: LaBella Associates, D.P.C
C/O: Mr. Brian Poplarchick
Re: ESASD 2200223; ESASD Smithfield ElementaryDate of Sampling: 01-22-2020
Date of Receipt: 01-23-2020
Date of Report: 01-27-2020**SPORE TRAP REPORT: NON-VIABLE METHODOLOGY**

Location:	003: Smithfield Elementary Rm. 118			004: Smithfield Elementary Rm. 111		
Comments (see below)	None			None		
Lab ID-Version‡:	11141358-1			11141359-1		
Analysis Date:	01/27/2020			01/27/2020		
	raw ct.	% read	spores/m3	raw ct.	% read	spores/m3
Ascospores						
Basidiospores				1	25	53
Chaetomium						
Cladosporium						
Curvularia						
Epicoccum						
Fusarium						
Myrothecium						
Nigrospora						
Other brown						
Other colorless						
Penicillium/Aspergillus types†	2	25	110	1	25	53
Pithomyces						
Rusts						
Smuts, Periconia, Myxomycetes	2	100	27	4	100	53
Stachybotrys						
Stemphylium						
Torula						
Ulocladium						
Zygomycetes						
Background debris (1-4+)††	2+			2+		
Hyphal fragments/m3	13			13		
Pollen/m3	< 13			< 13		
Skin cells (1-4+)	2+			3+		
Sample volume (liters)	75			75		
§ TOTAL SPORES/m3			130			160

Comments:

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

† The spores of *Aspergillus* and *Penicillium* (and others such as *Acremonium*, *Paecilomyces*) are small and round with very few distinguishing characteristics. They cannot be differentiated by non-viable sampling methods. Also, some species with very small spores are easily missed, and may be undercounted.

†† Background debris indicates the amount of non-biological particulate matter present on the trace (dust in the air) and the resulting visibility for the analyst. It is rated from 1+ (low) to 4+ (high). Counts from areas with 4+ background debris should be regarded as minimal counts and may be higher than reported. It is important to account for samples volumes when evaluating dust levels.

The analytical sensitivity is the spores/m³ divided by the raw count, expressed in spores/m³. The limit of detection is the analytical sensitivity (in spores/m³) multiplied by the sample volume (in liters) divided by 1000 liters.

For more information regarding analytical sensitivity, please contact QA by calling the laboratory.

‡ A "Version" indicated by -"x" after the Lab ID# with a value greater than 1 indicates a sample with amended data. The revision number is reflected by the value of "x".

§ Total Spores/m³ has been rounded to two significant figures to reflect analytical precision.

Client: LaBella Associates, D.P.C
C/O: Mr. Brian Poplarchick
Re: ESASD 2200223; ESASD Smithfield ElementaryDate of Sampling: 01-22-2020
Date of Receipt: 01-23-2020
Date of Report: 01-27-2020**SPORE TRAP REPORT: NON-VIABLE METHODOLOGY**

Location:	005: Smithfield Elementary Rm. 101			006: Smithfield Elementary Rm. 213		
Comments (see below)	None			None		
Lab ID-Version‡:	11141360-1			11141361-1		
Analysis Date:	01/27/2020			01/27/2020		
	raw ct.	% read	spores/m3	raw ct.	% read	spores/m3
Ascospores	1	25	53			
Basidiospores				2	25	110
Chaetomium						
Cladosporium						
Curvularia						
Epicoccum						
Fusarium						
Myrothecium						
Nigrospora						
Other brown						
Other colorless						
Penicillium/Aspergillus types†	1	25	53			
Pithomyces						
Rusts						
Smuts, Periconia, Myxomycetes	1	100	13			
Stachybotrys						
Stemphylium						
Torula						
Ulocladium						
Zygomycetes						
Background debris (1-4+)††	2+			1+		
Hyphal fragments/m3	< 13			< 13		
Pollen/m3	< 13			< 13		
Skin cells (1-4+)	2+			1+		
Sample volume (liters)	75			75		
§ TOTAL SPORES/m3			120			110

Comments:

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

† The spores of *Aspergillus* and *Penicillium* (and others such as *Acremonium*, *Paecilomyces*) are small and round with very few distinguishing characteristics. They cannot be differentiated by non-viable sampling methods. Also, some species with very small spores are easily missed, and may be undercounted.

†† Background debris indicates the amount of non-biological particulate matter present on the trace (dust in the air) and the resulting visibility for the analyst. It is rated from 1+ (low) to 4+ (high). Counts from areas with 4+ background debris should be regarded as minimal counts and may be higher than reported. It is important to account for samples volumes when evaluating dust levels.

The analytical sensitivity is the spores/m³ divided by the raw count, expressed in spores/m³. The limit of detection is the analytical sensitivity (in spores/m³) multiplied by the sample volume (in liters) divided by 1000 liters.

For more information regarding analytical sensitivity, please contact QA by calling the laboratory.

‡ A "Version" indicated by -"x" after the Lab ID# with a value greater than 1 indicates a sample with amended data. The revision number is reflected by the value of "x".

§ Total Spores/m³ has been rounded to two significant figures to reflect analytical precision.

Client: LaBella Associates, D.P.C
C/O: Mr. Brian Poplarchick
Re: ESASD 2200223; ESASD Smithfield ElementaryDate of Sampling: 01-22-2020
Date of Receipt: 01-23-2020
Date of Report: 01-27-2020**SPORE TRAP REPORT: NON-VIABLE METHODOLOGY**

Location:	007: Smithfield Elementary Rm. 121			008: Smithfield Elementary Exterior		
Comments (see below)	None			None		
Lab ID-Version‡:	11141362-1			11141363-1		
Analysis Date:	01/27/2020			01/27/2020		
	raw ct.	% read	spores/m3	raw ct.	% read	spores/m3
Ascospores				1	25	53
Basidiospores				2	25	110
Chaetomium						
Cladosporium						
Curvularia						
Epicoccum						
Fusarium						
Myrothecium						
Nigrospora						
Other brown						
Other colorless						
Penicillium/Aspergillus types†	1	25	53			
Pithomyces						
Rusts						
Smuts, Periconia, Myxomycetes						
Stachybotrys						
Stemphylium						
Torula						
Ulocladium						
Zygomycetes						
Background debris (1-4+)††	< 1+			2+		
Hyphal fragments/m3	< 13			< 13		
Pollen/m3	< 13			< 13		
Skin cells (1-4+)	< 1+			< 1+		
Sample volume (liters)	75			75		
§ TOTAL SPORES/m3			53			160

Comments:

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

† The spores of *Aspergillus* and *Penicillium* (and others such as *Acremonium*, *Paecilomyces*) are small and round with very few distinguishing characteristics. They cannot be differentiated by non-viable sampling methods. Also, some species with very small spores are easily missed, and may be undercounted.

†† Background debris indicates the amount of non-biological particulate matter present on the trace (dust in the air) and the resulting visibility for the analyst. It is rated from 1+ (low) to 4+ (high). Counts from areas with 4+ background debris should be regarded as minimal counts and may be higher than reported. It is important to account for samples volumes when evaluating dust levels.

The analytical sensitivity is the spores/m³ divided by the raw count, expressed in spores/m³. The limit of detection is the analytical sensitivity (in spores/m³) multiplied by the sample volume (in liters) divided by 1000 liters.

For more information regarding analytical sensitivity, please contact QA by calling the laboratory.

‡ A "Version" indicated by -"x" after the Lab ID# with a value greater than 1 indicates a sample with amended data. The revision number is reflected by the value of "x".

§ Total Spores/m³ has been rounded to two significant figures to reflect analytical precision.